






SPARE PARTS DIAGRAM FOR



Dish/Glass Washer
F80PR

First Choice Group
Blakeney Way, Kingswood Lakeside
Cannock, Staffs, WS11 8LD
TEL: 01543 577778 FAX: 01543504141
Email: enquires@firstchoice-cs.co.uk
Web: www.firstchoice-cs.co.uk



Code	Description	Validity Date
30G3190	DOOR ASS. Y	01/01/1998-
30M3640	BOTTOM PLATE	01/01/1998-
30Q0280	FILTER	01/01/1998-
30Q1510	FILTER Ø98 H=117	01/01/1998-
30T1340	RIGHT-HAND HINGE	01/01/1998-
30T1350	LEFT HAND HINGE	01/01/1998-
30T1370	GUIDE	01/01/1998-
30W0870	TANK	01/01/1998-
30Z1270	WASH BLADES	01/01/1998-10/06/1999
30Z2680	WASHING ARM	11/06/1999-11/06/1999
36G8540	WASH BLADES 495X58X16	12/06/1999-
30Z1440	RINSE ARM	01/01/1998-13/12/2007
30Z1491	COMPL. RINSE ARM	14/12/2007-
37M8900	NAME PLATE	01/01/1998-
37M7200	DOOR TRIM	01/01/1998-
3150230	GASKET	01/01/1998-
3150290	SUMP GASKET	01/01/1998-
3151770	GASKET	01/01/1998-
3152010	GASKET	01/01/1998-
3190360	PIN	01/01/1998-
31W0060	SPRING	01/01/1998-15/04/1998
31W0061	SPRING	16/04/1998-
32X0130	GROMMET Ø29-Ø37	01/01/1998-
32D0440	CABLE CLAMP	01/01/1998-
32D0840	LIVE TERMINAL	01/01/1998-
32D0860	GROUND TERMINAL	01/01/1998-
33Q4700	LOCK NUT	01/01/1998-
32D0850	TERMINAL	01/01/1998-
32D1220	TERMINAL CLAMPING BOARD	01/01/1998-
32D1230	"OMEGA" BRACKET	01/01/1998-
32G0400	HEATING EL.	01/01/1998-
3240720	HEATING ELEMENT	01/01/1998-
32M4760	MOTOR PUMP	01/01/1998-
32W0970	SWITCH	01/01/1998-
32W0980	SWITCH	01/01/1998-
32W1670	SIGNAL LAMP	01/01/1998-
32W0870	MAGNET	01/01/1998-
32W3240	MICROSWITCH	01/01/1998-
32X0120	GROMMETØ 21	01/01/1998-
32V0200	THERMOSTAT 30°- 90°	01/01/1998-
32Z2000	RELAY	01/01/1998-
32Z2011	SAFETY THERMOSTAT	01/01/1998-
32Z4801	RELAY	01/01/1998-
32Z8110	PROGRAMMER	01/01/1998-
3300390	DISCHARGE ASPIRATION	01/01/1998-
3300400	DISCHARGE	01/01/1998-
33D0750	DISPENSER	01/01/1998-
33M0240	VENT	01/01/1998-24/11/1999
33M1280	VENT	25/11/1999-

33M0300	SPACER	01/01/1998-
33D0660	RINSE AID TANK	01/01/1998-
33D1371	INLET WATER SOLENOID VALVE	01/01/1998-
33M0350	PIPE	01/01/1998-
33M0130	WASHING/RINSE HUB	01/01/1998-
33M0170	SUMP	01/01/1998-
33M0180	FLANGE	01/01/1998-
33M0490	PIPE	01/01/1998-
33M0220	AIR TRAP	01/01/1998-
33M0251	GUARD	01/01/1998-24/11/1999
33M0340	JOINT	01/01/1998-21/05/2006
3070540	WASHING INFER. PIPE FITTING	22/05/2006-
33M0360	FLANGE	01/01/1998-
33M0500	HUB+NUT	01/01/1998-
33Q2000	PIN	01/01/1998-
33Q1090	PIN	01/01/1998-
33Q1860	RING NUT	01/01/1998-
33Q1890	PIN	01/01/1998-
33M0580	RINSE COUPLING	01/01/1998-
34A0290	BOILER	01/01/1998-
35A0530	CONTAINER BACK	01/01/1998-
35D8720	BOTTOM PANEL	01/01/1998-
35D8740	LH SIDE PANEL	01/01/1998-
35D8730	RH SIDE PANEL	01/01/1998-
35D8750	BACK PANEL	01/01/1998-
35D8710	SOL. VALVE SUPPORT	01/01/1998-
35G2720	TOP PANEL	01/01/1998-
35G2120	DOOR	01/01/1998-
35S2290	ELECTRIC BOX	01/01/1998-
35S2300	COVER	01/01/1998-
35T0610	THERMOSTAT SUPPORT	01/01/1998-
131AA14	RUBBER HOSE Ø20x13	01/01/1998-
35V8380	PRESSOSTAT SWITCH SUPPORT	01/01/1998-
33M0630	STEAM CONDENSER	01/01/1998-
3150010	"O" RING	01/01/1998-
3601130	CONTROL BOARD	01/01/1998-
3601140	DOOR HANDLE	01/01/1998-
3601150	SIDE HEAD	01/01/1998-
3601190	HANDLE	01/01/1998-
32V0100	THERMOSTAT 30°-60°	01/01/1998-
36E0020	FOOT	01/01/1998-
36G1340	SPRING	01/01/1998-
36G2540	SPRING	01/01/1998-
36M1511	HANDLE	01/01/1998-
37M7190	CTRL BOARD BAND	01/01/1998-
35S2830	PUMP SUPPORT	01/01/1998-
37Q1320	GASKET	01/01/1998-
35Z0050	TRAP PLATE	01/01/1998-
32Z2430	THERMOSTAT	01/01/1998-
32Z2840	PRESSURE-SWITCH	01/01/1998-

32Z8310	AUXILIARY CONTACT	01/01/1998-
32Z8510	FILTER	01/01/1998-
3300410	PIPE	01/01/1998-
3300420	DRAIN PIPE	01/01/1998-
3300370	PIPE	01/01/1998-
131AA23	RUBBER HOSE Ø35 Ø28	01/01/1998-
35C8220	PROP. DÉVICE SUPPORT	01/01/1998-
3150321	HEAT.ELEM.PROTECTION	01/01/1998-
3150520	"O" RING	01/01/1998-
33D0810	DETERGENT COUPLING	01/01/1998-24/11/1999
33Q4440	DETERGENTCOUPL.	25/11/1999-
35E0040	MOTOR PUMP SUPPORT	01/01/1998-
3150430	"O" RING Ø 56.52	01/01/1998-
36G8540	WASH BLADES 495X58X16	01/01/1998-
36G8550	RINSE HUB	01/01/1998-
36R0030	PLUG	01/01/1998-
33T2740	SPRAYING NOZZLE	01/01/1998-
35X4020	RH RINSE ARM	01/01/1998-
35X4030	LH RINSE ARM	01/01/1998-
32M2920	RINSE PUMP	01/01/1998-
33D0130	OVERFLOW	01/01/1998-24/11/1999
33D2640	OVERFLOW	25/11/1999-31/12/2000
33D3120	OVERFLOW	01/01/2001-14/01/2014
33D0140	OVERFLOW	15/01/2014-
32Z4741	PRESSURE-SWITCH 30/70	01/01/1998-24/11/1999
32Z4741	PRESSURE-SWITCH 30/70	25/11/1999-
3150520	"O" RING	01/01/2001-