




SPARE PARTS DIAGRAM FOR




Bratt Pan
1A1BR2GA

First Choice Group
Blakeney Way, Kingswood Lakeside
Cannock, Staffs, WS11 8LD
TEL: 01543 577778 FAX: 01543504141
Email: enquires@firstchoice-cs.co.uk
Web: www.firstchoice-cs.co.uk




Code	Description	Validity Date
30W1131	WELL ASSEMBLY	16/07/1999-
35H0950	BACK PANEL	31/08/1999-27/06/2013
35H0951	BACK PANEL	28/06/2013-
35C7940	CONTROL BOARD ASS.Y	01/02/1999-
138AA02	GASKET	01/02/1999-
35G7900	SLOT COVER	01/02/1999-
36G5150	PIN	01/02/1999-
36G5180	SPRING	01/02/1999-
3070970	SPY-HOLE	01/02/2006-
35Y0860	BULB HOLDER	01/02/1999-
35R2971	OMEGA FRAME	17/10/2002-
36C2970	STAINLESS STEEL FOOT	01/02/1999-27/09/2015
3313390	STAINLESS STEEL FOOT	28/09/2015-
35A8420	REAR PANEL	01/02/1999-
35H1100	FRONT PANEL	30/06/1999-
35R2910	CONTROL PROTECTION	01/02/1999-
3170290	KNOB SPRING	01/02/1999-
32V0661	THERMOSTAT	01/02/1999-
3152240	THERMOSTAT PROTECT.	01/02/1999-
3106730	ORANGE LIGHT 230V	23/05/2007-
3106710	GREEN LIGHT 230V	23/05/2007-
35G7940	CONTROL PROTECTION	01/02/1999-
32X0120	GROMMET Ø 21	01/02/1999-
3600890	CONTROL PROTECTION	01/02/1999-
31B0820	SCREW TCB M5X45 CROSS	01/02/1999-
37Q4030	HEAT. ELEM. PROTECTION	01/02/1999-
35P1040	BUTTON GUARD	01/02/1999-
35R2990	RATIOMOTOR SUPPORT	01/02/1999-
35R4830	RATIOMOTOR SUPPORT	01/02/1999-
32M5470	RATIOMOTOR P0301/1956B	01/02/1999-
3152340	GASKET	01/02/1999-
36E0800	PLATE	01/02/1999-
35R4840	SUPPORT	01/02/1999-
31W0340	SCREW	01/02/1999-
36F0340	BEARING Ø35Ø17X12	01/02/1999-
36E0770	BUSHING Ø30 Ø17=15	01/02/1999-
31Z8110	LOCK PIN Ø 5X30	01/02/1999-
3100130	FEATHER	01/02/1999-
36E0400	BUSHING Ø30,Ø20=12	01/02/1999-
35R4850	HINGE	01/02/1999-
3122200	WASHER	01/02/1999-
35R3490	MOTOR PROTEC. PLATE	01/02/1999-
36G8900	BUSHING 20TPSX	01/02/1999-
30Q1800	EXT FLUE ASS. Y	16/10/2002-
36C1310	FLUE GUARD	01/02/1999-
30Z2370	GAS MANIFOLD	19/09/2003-
33Q3990	RING NUT	01/02/1999-
30G3740	COVER	01/02/1999-
36C2590	RH HINGE SUPPORT	01/02/1999-





36C2600	LH HINGE SUPPORT	01/02/1999-
36M3440	HANDLE	01/02/1999-31/12/2011
3061911	HANDLE	01/01/2012-
36H0260	HINGE SHAFT	01/02/1999-
36G2680	SPRING PIN	01/02/1999-
36H0350	SPRING	01/02/1999-
36E0440	PIN M5 Ø18Ø12	01/02/1999-
36E0870	SPACER	01/02/1999-
31W0280	SCREW	01/02/1999-
3003360	WATER PIPE	24/04/2003-
6300728	COCK ASSEMBLY	28/01/2009-
33Q3750	"NIPPLE M 1/2""G-Ø12"	01/02/1999-
33Q3760	"ELBOW 1/2""	01/02/1999-
3162200	RED RING KNOB	28/01/2009-
3003370	WATER PIPE	24/04/2003-
33Q3780	WATER SPOUT	01/02/1999-
33Q4000	NUT	01/02/1999-
36Q0460	BICONE Ø 18X9	01/02/1999-
35R7760	PROTECTED MICROSWITCH	29/04/1999-
32W3251	PROTECTED MICROSWITCH	01/02/1999-
32D0830	FAIRLEAD Ø 8	01/02/1999-
36G8100	LH SCREW Ø20X4 TP	01/02/1999-
36E1240	FLAT BRACKET	01/02/1999-
32W3300	BLACK SWITCH	01/02/1999-
32W3310	SUPPORT BASE	01/02/1999-
32W3320	AUXILIARY CONTACT N.O.	01/02/1999-
32W3330	AUXILIARY CONTACT N.C.	01/02/1999-
31V0290	SCREW	01/02/1999-
32M6060	M.F. REDUCTION	01/02/1999-
32M6050	MOTOR	01/02/1999-
36Q0140	BICONE NUT Ø 10	24/04/2003-
36Q0080	BICONE Ø 10X6.5	24/04/2003-
M002090	M.FRAME TILTING BRATT-P	01/02/1999-
M002030	EL. BOARD	01/02/1999-
M002120	M.CONB.CHAMBER COMPL.80	01/02/1999-
36G8160	SPRING	23/06/1999-
30T2710	FIXING M10 ASS.Y	23/06/1999-
36E1050	PIN	23/06/1999-
36E1910	LOCKING RING FOR GAS VALVE	30/06/1999-
3120410	WASHER	30/06/1999-
3127820	STOP RING Ø 30	15/11/2007-
35R7810	PROTECTED MICROSWITCH	16/07/1999-
35H0930	RH SIDE PANEL	31/08/1999-
35H0940	LH SIDE PANNEL	31/08/1999-
3031901	GASKET	01/02/2006-
3070980	SUPPORT GLASS	01/02/2006-



Code	Description	Validity Date
35P0790	PANEL BOARD	01/02/1999-
35G7950	EL. BOX COVER	01/02/1999-22/01/2006
35G7951	EL. BOX COVER	23/01/2006-
32V1170	FUSE-HOLDER	01/02/1999-
3200020	FUSE 5X20	01/02/1999-
32X0120	GROMMET Ø 21	01/02/1999-
32X0200	GROMMET Ø7.5-Ø11.5	01/02/1999-
32T0041	SPARK IGNITION DEVICE	01/02/1999-19/03/2001
32T0210	SPARK IGNITION DEVICE	20/03/2001-
32A1640	CABLE "HF" 150MM	01/02/1999-
32A0390	CABLE "HF" 1200MM	01/02/1999-
32D0171	TERMINAL BOARD	01/02/1999-
32D0191	FAIRLEAD	01/02/1999-
32D0200	LOCK NUT PG16	01/02/1999-
17RNL01	CABLE TERMINAL	01/02/1999-
32W3251	PROTECTED MICROSWITCH	01/02/1999-
32D0830	FAIRLEAD Ø 8	01/02/1999-
36D2170	MICROSWITCH SUPPORT	01/02/1999-
36D2110	ROD GUIDE	01/02/1999-
3128420	BENZING RING Ø 9	01/02/1999-
32D0080	TERMINAL BOARD	01/02/1999-
36E1100	MICROSWITCH ROD	01/02/1999-
32X0190	CABLE SUPPORT	01/02/1999-
32Q4600	CABLE ASS.Y	01/02/1999-19/03/2001
32Q4601	CABLE GROUP	20/03/2001-



Code	Description	Validity Date
30T3100	LH PANEL	01/02/1999-
30T3110	RH PANEL	01/02/1999-
35R5430	"L" BRACKET	01/02/1999-
3AA2610	FRONT CROSS MEMBER	01/02/1999-
36M3291	HINGE	05/03/2000-
31W0370	SCREW	05/03/2000-
35R5440	STIFFENING	01/02/1999-
30T3460	STIFFENING	01/02/1999-
35R0510	FLAT BRACKET	01/02/1999-
36E0430	PIN M12 CH20X34,5	01/02/1999-
35R3030	CROSS MEMBER	01/02/1999-
3003380	COCKS SUPPORT	24/04/2003-
35Q9450	PROTECTION	01/02/1999-01/05/2012
35Q9451	PROTECTION	02/05/2012-
35C7830	SIDE PANEL	01/02/1999-
30T3470	GUARD	01/02/1999-
30M6480	TOP ASS. Y	01/02/1999-22/12/2011
30M6481	TOP ASS. Y	23/12/2011-03/07/2013
30M6482	TOP ASS. Y	04/07/2013-
36G8170	LIFTING SHAFT ASS.	01/02/1999-
36C2870	PIN	01/02/1999-
36G8180	LIFTING ROD	01/02/1999-
36E0760	SPACER	01/02/1999-
36C2860	BUSHING	01/02/1999-
31Z0140	SPLIT PIN 3,2x25	01/02/1999-
35R2380	SUPPORT	01/02/1999-
36G8130	LEAD NUT 20TPN	01/02/1999-
36H0150	LEAD NUT SUPPORT	01/02/1999-
35E0160	BUSHING GUIDE	01/02/1999-
31Z8910	LOCKPIN Ø 4X10	01/02/1999-
36M6570	SCREW	20/07/1999-



Code	Description	Validity Date
6300491	EL. CONTROL ASS.Y	01/02/1999-
30T6140	HOB ASSEMBLY	16/07/1999-
35E0050	FLUE FRONT PLATE	01/02/1999-
35E0060	REAR FLUE	01/02/1999-
35E0230	FLUE SUPPORT	01/02/1999-
35E0600	BAFFLE	01/02/1999-
35E0080	STIFFENING	01/02/1999-
34A1431	BURNER 24KW	24/10/2002-
36C2310	BUSHING Ø 18	01/02/1999-
35E0090	BAFFLE	01/02/1999-
35E0100	BAFFLE	01/02/1999-
35E0110	BAFFLE	01/02/1999-
33Q4100	NOZZLE HOUSING	19/09/2003-
36Q1110	LOCK NUT 3/8"	01/02/1999-
33A1081	THREE-FLAME BURNER	24/04/2008-
33A0970	RING NUT	01/02/1999-
33A0690	PILOT BURNER BODY Ø0,40	02/09/2000-
33A0950	REAR BRACKET	01/02/1999-
33A1000	FRONT BRACKET	01/02/1999-
32T0010	IGNITION PLUG	27/01/2010-
131AA46	HOSE 8'X40	01/02/1999-
33A0320	THERMOCOUPLE 9x1x1500	01/02/1999-
33A1270	THERMOCOUPLE EXTENSION	01/02/1999-
35R2890	VALVE SUPPORT	01/02/1999-
33A0930	GAS THERMOST. NOVASIT 824 1/2" 50Hz	01/02/1999-
33A0020	COMPL. VALVE	01/02/1999-
3195600	CONNECTOR+CABLE+GASKET+SCREW	24/06/2011-
32A2340	TWO-POLE CONNECTOR	01/02/1999-
33G0620	HANDLE EXTENSION L=57	30/06/1999-30/07/2012
3227400	HANDLE EXTENSION	31/07/2012-
3152460	GAS VALVE PROTECTION	30/06/1999-
3038370	"TEFLON NIPPLE M/M 1/2"" Ø14"	20/10/2004-
30Z2130	DISTRIBUTOR GAS ASS.Y	01/02/1999-
3006940	GAS DISTRIBUTOR PIPE	19/09/2003-
35X4210	GAS DISTRIBUTOR PIPE	01/02/1999-
3006950	BURNER PIPE	19/09/2003-
35X4230	PILOT BURNER PIPE	01/02/1999-
35X4691	GAS VALVE PIPE	19/09/2003-
33Q4090	NIPPLE M 1/2-3/8 Ø14	19/09/2003-
36Q0310	BICONE Ø 14 X 10	10/01/2006-
36Q0210	BICONE NUT Ø 14	19/09/2003-