




SPARE PARTS DIAGRAM FOR




Bratt Pan
1A1BR2E

First Choice Group
Blakeney Way, Kingswood Lakeside
Cannock, Staffs, WS11 8LD
TEL: 01543 577778 FAX: 01543504141
Email: enquires@firstchoice-cs.co.uk
Web: www.firstchoice-cs.co.uk




Code	Description	Validity Date
30W2270	WELL ASS. Y	01/02/1999-
35H1150	BACK PANEL	20/07/1999-
35C8660	UPPER CONTROL BOARD	01/02/1999-
138AA02	GASKET	01/02/1999-
35Y0860	BULB HOLDER	01/02/1999-
137AA12	GASKET (U.M.=mt)	10/09/2004-
35R2971	OMEGA FRAME	17/10/2002-
36C2970	STAINLESS STEEL FOOT	01/02/1999-27/09/2015
3313390	STAINLESS STEEL FOOT	28/09/2015-
35A1660	REAR PANEL	01/02/1999-28/03/2012
35A1662	REAR PANEL	29/03/2012-
35H0020	FRONT PANEL MAN.	01/02/1999-
32Z0171	VOLTAGE REGULATOR	01/02/1999-
35R4270	COMMANDS PROTECTION	01/02/1999-
3170290	KNOB SPRING	01/02/1999-
32V0661	THERMOSTAT	01/02/1999-
3152240	THERMOSTAT PROTECT.	01/02/1999-
3106730	ORANGE LIGHT 230V	23/05/2007-
3106710	GREEN LIGHT 230V	23/05/2007-
35G8310	LID	01/02/1999-
32X0120	GROMMETØ 21	01/02/1999-
6300491	EL. CONTROL ASS.Y	01/02/1999-
6300493	EL. CONTROL ASS.Y	01/02/1999-
36M5562	CRANK Ø 200 AISI303	13/05/2003-25/09/2012
3214440	CRANK Ø 200 WITH HOLE	26/09/2012-24/10/2016
3342840	CRANK Ø 200 WITH HOLE	25/10/2016-
31A0130	SCREW M6X60	12/05/2000-
35R2920	BEARING SUPPORT	01/02/1999-
36G8121	SHAFT	12/05/2000-
31Z0100	LOCK PIN Ø 6X26	01/02/1999-
33Q4000	NUT	01/02/1999-
36C2830	BEARING SUPPORT	01/02/1999-
36F0340	BEARING Ø35Ø17X12	01/02/1999-
36G8110	LH SCREW	01/02/1999-
36E0770	BUSHING Ø30 Ø17=15	01/02/1999-
36E0400	BUSHING Ø30,Ø20=12	01/02/1999-
31Z8110	LOCK PIN Ø 5X30	01/02/1999-
36G8900	BUSHING 20TPSX	01/02/1999-
36G8160	SPRING	01/02/1999-
30T2710	FIXING M10 ASS.Y	01/02/1999-
36E1050	PIN	01/02/1999-
30G3740	COVER	01/02/1999-
36C2590	RH HINGE SUPPORT	01/02/1999-
36C2600	LH HINGE SUPPORT	01/02/1999-
36M3440	HANDLE	01/02/1999-31/12/2011
3061911	HANDLE	01/01/2012-
36H0260	HINGE SHAFT	01/02/1999-
36G2680	SPRING PIN	01/02/1999-
36H0350	SPRING	01/02/1999-


36E0440	PIN M5 Ø18Ø12	01/02/1999-
36E0870	SPACER	01/02/1999-
31W0280	SCREW	01/02/1999-
35R5950	SUPPORT "L"	01/02/1999-
3003360	WATER PIPE	24/04/2003-
36Q1290	PLUG	01/02/1999-
6300728	COCK ASSEMBLY	28/01/2009-
33Q3750	"NIPPLE M 1/2""G-Ø12"	01/02/1999-
33Q3760	"ELBOW 1/2"""	01/02/1999-
3162200	RED RING KNOB	28/01/2009-
3003370	WATER PIPE	24/04/2003-
33Q3780	WATER SPOUT	01/02/1999-
33Q3990	RING NUT	01/02/1999-
36Q0460	BICONE Ø 18X9	01/02/1999-
35R7760	PROTECTED MICROSWITCH	29/04/1999-
32W3251	PROTECTED MICROSWITCH	01/02/1999-
32D0830	FAIRLEAD Ø 8	01/02/1999-
36Q0140	BICONE NUT Ø 10	24/04/2003-
36Q0080	BICONE Ø 10X6.5	24/04/2003-
M004370	M.FRAME TILTING BRATT-PAN	01/02/1999-
M004540	EL. BOARD	01/02/1999-
M004390	HEATING EL. 800	01/02/1999-
35H0930	RH SIDE PANEL	20/07/1999-
35H0940	LH SIDE PANNEL	20/07/1999-



Code	Description	Validity Date
30T3100	LH PANEL	01/02/1999-
30T3110	RH PANEL	01/02/1999-
35R5430	"L" BRACKET	01/02/1999-
3AA2610	FRONT CROSS MEMBER	01/02/1999-
36M3290	HINGE	01/02/1999-04/03/2000
36M3291	HINGE	05/03/2000-
31W0310	SCREW TEI	01/02/1999-04/03/2000
31W0370	SCREW	05/03/2000-
35R5440	STIFFENING	01/02/1999-
30T3460	STIFFENING	01/02/1999-
35R0510	FLAT BRACKET	01/02/1999-
35R3030	CROSS MEMBER	01/02/1999-
35R2900	COCKS SUPPORT	01/02/1999-23/04/2003
35Q9450	PROTECTION	01/02/1999-01/05/2012
35C7830	SIDE PANEL	01/02/1999-
35C8670	PROTECTION	01/02/1999-
30M7210	HOB ASS. Y	01/02/1999-12/01/2012
35R7020	SECTION	01/02/1999-
36G8170	LIFTING SHAFT ASS.	01/02/1999-
36C2870	PIN	01/02/1999-
36G8180	LIFTING ROD	01/02/1999-
36E0760	SPACER	01/02/1999-
36C2860	BUSHING	01/02/1999-
31Z8910	LOCKPIN Ø 4X10	01/02/1999-
35R2380	SUPPORT	01/02/1999-
36G8130	LEAD NUT 20TPN	01/02/1999-
36H0150	LEAD NUT SUPPORT	01/02/1999-
35E0160	BUSHING GUIDE	01/02/1999-
30T3890	TOP EL. ASS. Y	01/02/1999-28/04/1999
30T4030	TOP EL. ASSEMBLY	29/04/1999-
36M6570	SCREW	20/07/1999-



Code	Description	Validity Date
35X4760	DIFFUSER	01/02/1999-
32G2480	HEATING EL. 2000W/230V	01/02/1999-18/09/2001
32G2481	HEATING ELEMENT 2000W	19/09/2001-
35R4280	SLIDE	01/02/1999-
35R4300	HEATING EL. COVERING	01/02/1999-
35H0320	INS. PANEL COVERING	01/02/1999-
37Q4130	INSULANTING PANEL	01/02/1999-
35C8610	INS. PANEL COVERING	01/02/1999-
35H0870	TERMINALS PROTECTION	29/04/1999-
3200100	METALLIC HOSE	01/02/1999-
3201660	METALLIC HOSE NIPPLE	01/02/1999-
36Q1100	LOCK NUT 3/4"	01/02/1999-
35T3540	BULB HOLDER	01/02/1999-
35R7750	SECTION OMEGA	29/04/1999-



Code	Description	Validity Date
35P1260	EL. BOX	01/02/1999-
35G8320	EL. BOX PROTECTION	01/02/1999-06/02/2006
35G8321	EL. BOX PROTECTION	07/02/2006-
32X0200	GROMMET Ø7.5-Ø11.5	01/02/1999-
32X0140	GROMMET Ø 16	01/02/1999-
35R7060	\ "OMEGA\ " BRACKET	01/02/1999-
32Z2091	RELAY 220/230V-40A-50/60Hz	01/02/1999-
32D0651	TERMINAL	01/02/1999-23/01/2002
32D1740	TERMINAL	24/01/2002-
32D0641	FUSE TERMINAL BOARD	01/02/1999-23/01/2002
32D1730	FUSE TERMINAL BOARD	24/01/2002-
3200020	FUSE 5X20	01/02/1999-
32D0970	GROUND TERMINAL	01/02/1999-
32D0950	LIVE TERMINAL	01/02/1999-
32D0960	TERMINAL END COVER	01/02/1999-
32D0870	TERMINAL CLAMP	01/02/1999-
32X0120	GROMMETØ 21	01/02/1999-
32D0770	FAIRLEAD 8/10-17/20	01/02/1999-
32Z9201	SAFETY THERMOSTAT	01/02/1999-09/11/2004
32Z9202	SAFETY THERMOSTAT	10/11/2004-
37Q2100	HEAT. ELEM. PROTECTION	01/02/1999-
32D0030	TERMINAL BOARD	01/02/1999-
32D1450	TERMINAL	01/02/1999-
17RNL01	CABLE TERMINAL	01/02/1999-
32X0190	CABLE SUPPORT	01/02/1999-
32Q4540	EL. CABLES 1A1BR1E	01/02/1999-