




SPARE PARTS DIAGRAM FOR




Bratt Pan
191BR2E



First Choice Group
Blakeney Way, Kingswood Lakeside
Cannock, Staffs, WS11 8LD
TEL: 01543 577778 FAX: 01543504141
Email: enquires@firstchoice-cs.co.uk
Web: www.firstchoice-cs.co.uk



Code	Description	Validity Date
131AA12	RUBBER HOSEØ17Ø10 X H²O	01/03/2006-
3015790	HANDLE	01/03/2006-13/03/2008
3015791	HANDLE	14/03/2008-
3015870	ELECTRIC CONTROL KNOB	01/03/2006-16/03/2008
3015871	ELECTRIC CONTROL KNOB	17/03/2008-
3038871	CONTROL BOARD	01/03/2006-
3061901	COVER	01/03/2006-13/01/2013
3061903	COVER	14/01/2013-
3061911	HANDLE	01/03/2006-
3065570	WATER PIPE	01/03/2006-
3065940	FRONT PANEL MAN.	01/03/2006-
3066000	SWITCH	01/03/2006-27/01/2008
6300674	SWITCH	28/01/2008-
3140230	12/20 PIPE CLAMP	01/03/2006-
3152240	THERMOSTAT PROTECT.	01/03/2006-
3170290	KNOB SPRING	01/03/2006-
31D0040	SCREW	01/03/2006-20/02/2013
3232650	SCREWEW M5X30	21/02/2013-
32V0661	THERMOSTAT	01/03/2006-
32W0791	ORANGE LIGHT 230V	01/03/2006-22/05/2007
3106730	ORANGE LIGHT 230V	23/05/2007-
32W1331	GREEN LIGHT 230V	01/03/2006-22/05/2007
3106710	GREEN LIGHT 230V	23/05/2007-
32W1341	RED LIGHT 230V	01/03/2006-22/05/2007
3106720	RED LIGHT 230V	23/05/2007-
32X0120	GROMMETØ 21	01/03/2006-
32Z0171	VOLTAGE REGULATOR	01/03/2006-
33D1371	INLET WATER SOLENOID VALVE	01/03/2006-
33Q3780	WATER SPOUT	01/03/2006-
33Q3990	RING NUT	01/03/2006-
33Q4000	NUT	01/03/2006-
35R2972	OMEGA FRAME	01/03/2006-
36C2590	RH HINGE SUPPORT	01/03/2006-
36C2600	LH HINGE SUPPORT	01/03/2006-
36E0440	PIN M5 Ø18Ø12	01/03/2006-
36E0870	SPACER	01/03/2006-
36G2680	SPRING PIN	01/03/2006-
36H0260	HINGE SHAFT	01/03/2006-
36H0350	SPRING	01/03/2006-
36Q0460	BICONE Ø 18X9	01/03/2006-
36Q1100	LOCK NUT 3/4"	01/03/2006-
3055351	WELL ASS. Y	01/03/2006-



Code	Description	Validity Date
3062320	BUSHING	01/03 / 2006-
30T2710	FIXING M10 ASS.Y	01/03 / 2006-
36C2830	BEARING SUPPORT	01/03 / 2006-
36C2870	THE BATTERY	01/03 / 2006-
36E0400	BUSHING Ø30, Ø20 = 12	01/03 / 2006-
36E0770	BUSHING Ø30 Ø17 = 15	01/03 / 2006-
36E1050	THE BATTERY	01/03 / 2006-
36F0340	BEARING Ø35Ø17X12	01/03 / 2006-
36G8110	LH SCREW	01/03 / 2006-
36G8121	SHAFT	01/03 / 2006-
36G8130	LEAD NUT 20TPN	01/03 / 2006-
36G8160	SPRING	01/03 / 2006-
36G8180	LIFTING ROD	01/03 / 2006-
36G8900	BUSHING 20TPSX	01/03 / 2006-
36M5562	CRANK Ø 200 AISI303	01/03 / 2006-25 / 09/2012
3214440	CRANK Ø 200 WITH HOLE	26/09 / 2012-24 / 10/2016
3342840	CRANK Ø 200 WITH HOLE	25/10 / 2016-
6010051	LIFTING SHAFT ASSEMBLY	01/03 / 2006-



Code	Description	Validity Date
3200020	FUSE 5X20	01/03/2006-
32D0030	TERMINAL BOARD	01/03/2006-
32D0870	TERMINAL CLAMP	01/03/2006-
32D0950	LIVE TERMINAL	01/03/2006-
32D0960	TERMINAL END COVER	01/03/2006-
32D0970	GROUND TERMINAL	01/03/2006-
32D1450	TERMINAL	01/03/2006-
32D1730	FUSE TERMINAL BOARD	01/03/2006-
32D1740	TERMINAL	01/03/2006-
32D1780	FAIRLEAD	01/03/2006-
32G2481	HEATING ELEMENT 2000W	01/03/2006-
32W1660	MICROSWITCH	01/03/2006-10/03/2008
32W3340	MICROSWITCH	11/03/2008-
32X0140	GROMMET Ø 16	01/03/2006-
32X0200	GROMMET Ø7.5-Ø11.5	01/03/2006-
32Z2091	RELAY 220/230V-40A-50/60Hz	01/03/2006-12/04/2007
3110890	RELAY 230V 50/60Hz	13/04/2007-
32Z9202	SAFETY THERMOSTAT	01/03/2006-
35R4280	SLIDE	01/03/2006-
35T3540	BULB HOLDER	01/03/2006-
37Q3270	SWITCH COVER	01/03/2006-
32X0120	GROMMETØ 21	01/03/2006-